


Wireless Hotspot User Guide

Activating the Wireless Hotspot


1. Unpack the Android phone
2. On the right side of the phone, hold the bottom button to power on the device
3. When the screen appears, swipe down from the top
4. Tap the Hotspot icon to start the hotspot
 - a. **NOTE:** THE PHONE HAS BEEN LOCKED WITH A SCREEN PASSCODE. PARENTS WILL NOT NEED TO UNLOCK THE PHONE FOR THE WIFI HOTSPOT TO WORK.

Connecting to the Hotspot


1. Power on your Chromebook
2. In the bottom right corner of the screen, click on the wireless icon (shown below)




3. Click on the Wireless option (shown below)



4. Choose the **JCSCHOOLS** hotspot from the menu (shown below)



5. Enter the password: **JCSCHOOLS2020**
6. Click connect



7. You are now connected to the JCSCHOOLS hotspot